

Mobile Lone Worker

Designed to work with an existing mobile phone to offer safety for people who are working alone, travelling or working in potentially hazardous environments.



What is Mobile Lone Worker?

The Mobile Lone Worker System is designed to work with an existing mobile phone to offer safety for people who work alone, working mobile or working in potentially hazardous environments. Providing regular check up calls and easy duress activation, the Mobile Lone Worker System aims to quickly identify workers who may need assistance.

How Does it Work?

When a worker commences their shift for the day they log on using a short cut key programmed into their mobile phone. The worker is then able to record a message in the system, notifying of their movement for the day, or period of time. At this point they also select if and when they would like their check-up calls throughout the day.

When the check-up time comes, the system dials the worker to request their PIN. If they do not answer their phone it will try them two more times before an alarm is raised. The alarm response procedure will be customised to each individual and may involve listening to their pre-recorded message to determine their location and contacting their supervisor or emergency services to notify them of the situation.

If the worker does answer and successfully enter their PIN, the system will simply dial again at the next set time.

In an emergency the worker can press number 5 on their phone, which will immediately call the response centre, notifying them that the worker is in a duress situation.

Who is it for?

Tunstall's Lone Worker System is suitable for people who work alone or are very mobile.

- Community nurses
- Care workers
- Security workers
- Real Estate agents
- Night shift workers
- Mobile workers
- Sales representatives
- Any employees who travel regularly

Features and Benefits

- Provides a safer working environment
- Designed to work on most current mobile phones
- Useable as a time sheet to validate hours worked
- Helps management to easily track staff activity
- Provides a quick and easy to use duress call
- Service available 24 hours, 7 days a week

Fixed Location Lone Worker

Designed to be used by people who work on their own or in a potentially hazardous environment. A personal radio trigger or sensor device is worn by the worker allowing for easy duress activation.



What is Fixed Location Lone Worker?

Fixed Location Lone Worker systems are often used by people who work on their own or in potentially hazardous environment. A personal radio trigger or sensor device is worn by the worker allowing for easy duress activation.

How Does it Work?

Fixed Location Lone Worker uses an alarm unit that can be activated by a personal radio trigger or sensor. Multiple personal radio triggers and sensors can be programmed into any one alarm, allowing multiple people, activities and environmental changes to be monitored. When the alarm is activated by a radio trigger or sensor it dials Tunstall's 24 hour response centre or a designated responder.

The Tunstall response centre will notify the worker's designated responder, such as team leader or manager and if necessary contact emergency services for assistance.

The alarm features a super sensitive microphone and powerful speaker for two way hands free communication. This allows the worker to speak over the alarm even when not within close proximity of the alarm.

Each personal radio trigger has a unique code allowing the response centre to

identify which worker has activated an alarm.

Additionally, the personal radio trigger will activate an alarm call from up to 50 metres from the alarm unit and can be worn on the wrist, clipped to a belt or worn around the neck as a pendant.

The sensors that can be monitored include Tunstall's smoke detectors, flood detectors, gas detectors and more, alerting of a potentially hazardous environmental situation.

Who is it for?

Lone worker is suitable for people who work alone or in potentially hazardous environments.

- Warehouse workers
- People working with chemicals
- Night shift workers
- Teachers
- Hostel workers
- Overnight care providers
- Any employees working alone in a fixed location

Features and Benefits

- Provides a safer working environment
- Provides an easy to use duress call
- Provides a quick and easy way of alerting others of an emergency
- Provides extra reassurance to workers and their supervisors
- Service available 24 hours, 7 days a week